

HALF LIFT KIT

Installation Instructions

1. Remove the seat and tank.
2. Screw the hex front seat riser using a 3/4" or 19mm box wrench.
3. Screw the rectangular rear tank riser to the frame.
4. Mount the tank using the stock bolts.
5. Mount the rear seat tank riser to the frame with the 6mm bolts provided.
6. Take the hex bolts out of the bottom of the front seat riser and remove the clamps.
7. Using a ruler, place the front seat mount on the frame rails 8.25" from the rear mount. Install clamps and tighten.
8. Grease the holes in both the front and rear seat risers.
9. Slide tubes into the rear seat support from the back and have the bent tubes facing each other and level. The tubes should be flush with the front seat riser.
10. Tighten the pinch bolts on the sides of the front seat riser.
11. Mount the seat. Ensure that the front tabs on the seat clip into the front seat riser slots.

